

POWERFLEX®

PART NUMBER
PFR5-422

DESCRIPTION
REAR SUBFRAME REAR MOUNTING BUSH

INSTALLATION GUIDE

Product description:

Polyurethane bush to replace the rear subframe rear bush offering a positive location of the rear subframe.

Contents (parts per pack):

- 2 x bushes
- 2 x alloy sleeves
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove rear subframe rear bush.
2. The new Powerflex bush is fitted into the subframe from the top.
3. Lubricate the tapered end of the bush and the subframe with washing up liquid (this helps the bush slide in) place the tapered end into the top side of the hole on the subframe and pull/or push the bush through.

Fitting tip: start the bush taper in the subframe at an angle then pull the bush through with a length of stud, a washer on top of the bush and under the subframe, wind the nuts up and the bush will pull through.

4. Make sure the bottom lip `pops` out of the subframe to secure the bush in place.
5. Lubricate the bore of the bush with the supplied grease and insert the alloy sleeve.
6. Refit to car as necessary using the original lower washer.

