PART NUMBER

PFF85-1202

DESCRIPTION

FRONT ARM REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x bushes
2 x stainless steel sleeves
1 x grease

Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.
It is recommended that:
- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the arm from the car.
2. Remove the original rear bush from the arm, clean any dirt and rust from the arm.
3. The new bush fits in from the flat face with the radius.
4. Apply some washing up liquid to the smaller end of the bush, place the smaller end of the bush into the radius face of the arm then push the bush into the arm.

   Tip, put one edge into the arm, don't push it square.
5. Make sure the smaller lip comes through the other side of the arm to secure the bush into position.
6. Apply some of the supplied grease to the bore of the bush and the outside of the sleeve, push the sleeve into the bush..
7. Refit the arm back onto ''

POWERFLEX
progression in suspension